

## Supercal 739

### Compact Thermal Energy Meter

**Single-Jet Meter**



**Coaxial Multi-Jet Meter  
with G 2" thread**



**Coaxial Multi-Jet Meter  
with M77x1.5 thread**



#### Application

The **Supercal 739** is an autonomous compact thermal energy meter consisting of a flow meter an integrator and a pair of temperature sensors.

It's used in home automation, local and district heating/cooling systems to measure the consumption of heating or cooling energy for the individual heat cost billing. It's made to measure lower flows and energies.

The compact thermal energy meter **Supercal 739** meets the requirements of the European guideline MID-2004/22/EC and the standard EN 1434.

The compact heat meter **Supercal 739** is available as a single-jet meter and as coaxial multi-jet meters (G2" or M77x1.5) for flows  $q_p$  0.6,  $q_p$  1.5 and  $q_p$  2.5  $\text{m}^3/\text{h}$ . The compact design and the detachable integrator offer the best flexibility for difficult installation environments.

The **Supercal 739** can be used for the measurement of heating energy, cooling energy or a combination of heating / cooling energy in the temperature range of 5°C – 90°C. Through its two additional and optional pulse inputs, it's possible to connect, e.g. two water meters (hot and cold) and read them remotely via the heat meter.

## Main features

- Easy to operate and read
  - Non-volatile EEPROM memory
  - 18 monthly values for heating energy, volume, cooling energy, the additional pulse inputs 1 and 2 and the set day values
  - The **Supercal 739** is suitable for all communication environments:
    - Optical interface, M-Bus, powered over M-bus line, bi-directional radio, Wireless M-Bus (OMS compatible) and two pulses outputs
  - Two pulses inputs
  - Self-monitoring of conditions

## Versions

The **Supercal 739** is available in the following versions:

- Flow meter from  $q_p$  0.6  $\text{m}^3/\text{h}$ ,  $q_p$  1.5  $\text{m}^3/\text{h}$ ,  $q_p$  2.5  $\text{m}^3/\text{h}$  with
    - Single jet flow sensor
    - Coaxial multi-jet flow sensor with G2" thread
    - Coaxial multi-jet flow sensor with M77x1,5 thread
  - **Default configuration:**
    - Heat meter MID, temperature sensors Ø 5 mm, 1.5m
    - Optical interface
    - Battery 6+1 years

## Options Supercal 739

\* Thermal version:

## Heating energy and volume

◦ Heating / cooling version:

#### Heating and cooling energy

## Functions

- Recording of heating energy or combined heating/cooling energy by means of measuring the flow and the temperature difference.
  - Possibility to connect two additional pulse inputs
  - Displaying consumption data:
    - Displaying 18 monthly energy and volume values
    - Displaying 18 monthly cooling energy
    - Displaying 18 monthly values of the additional pulse input 1
    - Displaying 18 monthly values of the additional pulse input 2
    - Set day values
    - Displaying operating data
    - Self-monitoring with error display

## Flow sensor

Mechanical flow meter for flows  $q_p$  0.6  $m^3/h$ ,  $q_p$  1.5  $m^3/h$ ,  $q_p$  2.5  $m^3/h$  and a temperature range from 5°C – 90°C with the following flow sensors :

- Single jet flow sensor
- Coaxial multi jet flow sensor with G2" thread
- Coaxial multi jet flow sensor with M77x1,5 thread

## Temperature sensors


The pair of temperature sensors Pt 1'000 is connected to the integrator and is an integral part of the heat meter. By default the cold side sensor is mounted (and sealed) in the flow sensor. The temperature sensors mustn't be changed or modified.


## Integrator

The integrator is equipped with a large 8-digits display and can be rotated by 360°. The integrator can be separated from the flow sensor and be installed separately. A cable of 0,6 meter connects the integrator to the flow sensor. The housing of the integrator got a protection degree of IP65 against dust and humidity.

## Display

The LCD display of the **Supercal 739** has a large, clear design and high contrast, making it easy to read the data.



**Display sequences**


**Error messages**

Err 1	Flow higher than 1.2 x qs or faulty flow sensor.
Err 2	Measured temperature out of range or faulty temperature sensor.

**Measuring principle**

The medium flowing through the system drives the impeller wheel and the rotational speed is scanned electronically using a magnet (single jet) or inductive (coaxial multiple jet) principle detection. The temperature difference in the supply and return line is measured with a pair of platinum temperature sensors (Pt 1'000).

**Energy calculation**

The flow sensor records the flow. Using a microprocessor, the integrator calculates the temperature difference and calculates the thermal energy, respectively the heating/cooling energy, consumed using the average flow and the heat coefficient.

**Cooling energy**

The cooling energy will be cumulated if the two following conditions are fulfilled:

- (Δt) Temperature difference > -0.5K
- Supply temperature < 18°C

The threshold value of the temperature is set by default at 18°C. If necessary, the threshold value can be incremented in steps of 1°C using the optical head. The cooling energy has the same physical unit as the heating energy. If the integrator is used for the combined heating/cooling measurement, the cooling energy, cooling power and the temperature difference are displayed with a minus sign (-) and the values will be stored in the Tariff 1 register.

**Non-volatile memory**

The device parameters, as well as the cumulative values for energy and volume, cooling energy, monthly values, set day values, values of the pulses input counters 1 and 2, operating hours and error type are stored in a non-volatile memory (EEPROM), where they are saved even in case of a power failure (e.g. changing batteries). Once per hour and in the event of battery failure, the cumulative values are updated in the EEPROM.

**Monthly values**

At the end of each month, the monthly values are stored. A total of 18 monthly values of heat energy, volume, cooling energy and of the additional pulses inputs 1 and 2 are memorized in the integrator.

**Pulse inputs**

As an option the **Supercal 739** offers the possibility to integrate beneficially up to two additional pulse inputs such as a hot and cold water meter.

**Communication options**

Several communication interfaces are available (see the options table). The configuration of the communication option of the **Supercal 739** can be carried out with the free software Prog739-749 available from Sontex.

## TECHNICAL DATA SUPERCAL 739

### Integrator

#### Temperature measurement

Temperature sensor 2 wires	Pt1'000
Diameter	Ø5.0; Ø5.2, Ø 6 mm
Cables length	1.5 m
Admissible range	0...110°C
Differential range	3...75 K
Response limit	0.5 K
Temperature resolution (display)	0.1 K
Temperature resolution $\Delta t$	0.01 K
Measurement cycle	from 10 seconds

### Environment class

Environment class	C
Mechanics	M1
Electronics	E1
Battery protection class	III
Cable connection between flow sensor and integrator	0.6 m, fix
Protection index	IP 65

### Permissible temperature range

Operation	5...55°C
Operation: radio version	5...40°C
Storage and transport	-10...60°C

### Display

8-digits LCD
--------------

### Display units

Energy	kWh, MWh, MJ, GJ
Volume	$m^3$
Additional pulse inputs:	Volume or pulses
Temperature	°C
$\Delta$ Temperature	K

### Power supply

Lithium battery 3V	6+1 or 12+1 years
--------------------	-------------------

### Pulse output

Open collector	1 Hz, 500 ms
$V_{cc,max}$ : 50V <sub>DC</sub> ; $I_{cc,max}$ : 0,1 A	

### Pulse inputs with a dry contact

Power supply <sub>internal</sub>	3 V <sub>DC</sub>
$R_{pull\ UP}$ <sub>internal</sub>	2 MΩ
Protection	50 V <sub>DC</sub>
Pulse factor	0...999.999 m <sup>3</sup> /Imp or without unit


### Single Jet Flow Sensor

qp	Threaded connection		Mounting length	Mat.	PN	Maximal flow qs	Minimal flow qi	Low flow threshold value (50°C)	Threaded hole for sensor	Weight	Kvs value (20°C)	Pressure loss at qp
m³/h	G"	DN	mm		bar	m³/h	l/h	l/h		kg	m³/h	bar
(EN ISO 228-1)												
0.6	3/4"	(15)	110	Br	16	1,2	12 / 24	3	Yes	0.8	1.2	0.25
1.0	3/4"	(15)	110	Br	16	2.0	10 / 20	3	Yes	0.9	2.1	0.23
1.5	3/4"	(15)	110	Br	16	3,0	15 / 30	3	Yes	0.9	3.1	0.23
1.5	1"	(20)	130	Br	16	3,0	15 / 30	3	Yes	1.0	3.1	0.23
2.5	1"	(20)	130	Br	16	5,0	25 / 50	8	Yes	1.1	5.2	0.23

\*(h / v): Horizontal mounting / vertical mounting; Br: brass

16 bar = 1.6 MPa

### Pressure loss curve



### Metrological class

EN 1434 class 3

### Mounting

Long term operating temperature

15°C - 90°C

### Dimensions

Dimensions integrator

110.2 mm x 87.1 mm

Total Height

91.7 mm

Height from the axis of the tube

74.4 mm


Height without integrator

38.9 mm

**Sontex**

■ Thermal Energy ■ Flow Metering ■

**Supercal 739**




**Coaxial Multiple Jet Flow Sensor with G2" connection**

qp	Threaded connection		Mounting length	Mat.	PN	Maximal flow qs	Minimal flow qi	Low flow threshold value (50°C)	Threaded hole for sensor	Weight	Kvs value (20°C)	Pressure loss at qp
m³/h	G"	DN	mm		bar	m³/h	l/h	l/h		kg	m³/h	bar
	(EN ISO 228-1)											
**0.6	3/4"	(15)	110	Br	16	1,2	12	8	Yes	0.6	-	-
1.5	3/4"	(15)	110	Br	16	3,0	15	10	Yes	0.6	3.4	0.19
1.5	1"	(20)	130	Br	16	3,0	15	10	Yes	0.6	3.4	0.19
**2.5	1"	(20)	130	Br	16	5,0	25	17	Yes	0.7	-	-

\*EAS: base    \*\*in the pipeline;    Br: brass

16 bar = 1.6 MPa

**Pressure loss curve**

**Metrological class**

EN 1434 class 3

**Mounting**

 External thread of the coaxial part  
 Long term operating temperature

 G2"  
 15°C - 90°C

**Dimensions**


 Dimensions integrator  
 Total height  
 Height from the base  
 Height without integrator

 110.2 mm x 87.1 mm  
 90.6 mm  
 77.7 mm  
 42.2 mm

**Sontex**

■ Thermal Energy ■ Flow Metering ■

**Supercal 739**




### Coaxial Multiple Jet Flow Sensor with M77x1.5 connection

#### Flow metering

qp	Threaded connection		Mounting length	Mat.	PN	Maximal flow qs	Minimal flow qi	Low flow threshold value (50°C)	Threaded hole for sensor	Weight	Kvs value (20°C)	Pressure loss at qp
m³/h	G"	DN	mm		bar	m³/h	l/h	l/h		kg	m³/h	bar
	(EN ISO 228-1)											
**0.6	3/4"	(15)	110	Br	16	1,2	12	8	Yes	0.8	-	-
1.5	3/4"	(15)	110	Br	16	3,0	15	10	Yes	0.8	3.4	0.19
1.5	1"	(20)	130	Br	16	3,0	15	10	Yes	0.8	3.4	0.19
**2.5	1"	(20)	130	Br	16	5,0	25	17	Yes	0.9	-	-

\*EAS: base      \*\*in the pipeline;      Br: brass  
 16 bar = 1.6 MPa

#### Pressure loss curve



#### Metrological class

EN 1434 class 3


#### Mounting

External thread of the coaxial part  
 Long term operating temperature

M77x1.5  
 15°C - 90°C

#### Dimensions

Dimensions integrator	110.2 mm x 87.1 mm
Total height	120.1 mm
Height from the middle of the base	106.1 mm
Height without integrator	70.6 mm



#### Technical support

For technical support, please contact your local Sontex representation or Sontex SA directly.

#### Hotline Sontex:

[sontex@sontex.ch](mailto:sontex@sontex.ch)

+41 32 488 30 04

#### CE conformity according to

Directive 2004/22/EG (MID)

R & TTE guideline 1999/5/EC

Detailed declarations of conformity can be found on our homepage:

[www.sontex.ch](http://www.sontex.ch)

Modifications subject to change without notice

Data Sheet Supercal 739 EN 14-11-2013

© Sontex SA 2013